

#### LA-UR-19-28568

Approved for public release; distribution is unlimited.

Title: REGULATORY GUIDANCE FOR PACKAGING RADIOACTIVE SOURCES EXERCISES

Author(s): Matzke, James Lee

Intended for: Training for Chinese Delegation at Sandia National Laboratories, Sept.

10, 2019

Issued: 2019-08-23



### REGULATORY GUIDANCE FOR PACKAGING RADIOACTIVE SOURCES EXERCISES

#### Jim Matzke

#### **IAEA Nuclear Security Series No. 9**

# SECURITY IN THE TRANSPORT OF RADIOACTIVE MATERIAL IMPLEMENTING GUIDE

- 4.1. PRUDENT MANAGEMENT PRACTICES
- 4.2. BASIC SECURITY LEVEL
- 4.3. ENHANCED SECURITY LEVEL
- 4.4. ADDITIONAL SECURITY MEASURES


#### **A.1. ESTABLISHING SECURITY LEVELS**

- Per package: Enhanced security provisions would be applied when any package in a consignment exceeds the threshold value.
- Per conveyance: Enhanced security provisions would be applied when the total activity on a conveyance exceeds the threshold.

## A.2. SPECIFICATION OF THE TRANSPORT SECURITY THRESHOLD

To facilitate the undertaking of the transport security measures, the following definition of 'high consequence' radioactive material is used; 3000 A<sub>2</sub> in a single package, except for the following radionuclides:

Radionuclide	Transport security threshold(TBq)	
Am-241	0.6	
Au-198	2	
Cd-109	200	
Cf-252	0.2	
Cm-244	0.5	
Co-57	7	
Co-60	0.3	
Cs-137	1	
Fe-55	8000	
Ge-68	7	
Gd-153	10	
Ir-192	0.8	
Ni-63	600	
Pd-103	900	
Pm-147	400	
Po-210	0.6	
Pu-238	0.6	
Pu-239	0.6	
Ra-226	0.4	
Ru-106	3	
Se-75	2	
Sr-90	10	
T1-204	200	
Tm-170	200	
Yb-169	3	



You are on a recovery team that will be responsible for packaging and transporting the source shown in the photograph above.

Co-60 
$$A_1 = 1 \text{ TBq}$$
  $A_2 = 0.4 \text{ TBq}$ 

#### Question #1

With the original activity of 5210 Ci (192.77 TBq), what type of package would be required to for transport?

#### Question #2

With the decayed activity of 7.19 TBq, what type of package would be required to for transport?

#### **Question #3**

#### **Drum Evaluation**

Background: A 10 Ci (0.37 TBq) Am-241Be special form source is to be packaged.

Am241  $A_1 = 10 \text{ TBq}$   $A_2 = 0.001 \text{ TBq}$ 

#### Question #1

What type of package would be required to for transport?

#### Question #2

After the source is packaged, the dose rates are:

#### **Contact:**

Gamma – 0.01 mSv/hr

Neutron – 0.20 mSv/hr

#### 1 meter:

Gamma - 0.005 mSv/hr

Neutron – 0.02 mSv/hr

What is the Transport Index (T.I.) for this drum?

#### Question #3

Which radioactive label (white – I, yellow – II, yellow – III) is required?

Category	Maximum radiation	Transport Index
	level on external surface	(mSv/hr x 100)
I-White	≤ 0.005 mSv/h	0 (less than 0.05)
II-YELLOW	> 0.005 mSv/h ≤ 0.5 mSv/h	> 0 ≤ 1
III-YELLOW	>0.5 mSv/h ≤ 2 mSv/h	> 1 ≤ 10
III-YELLOW (transported as exclusive use)	> 2mSv/h ≤ 10 mSv/h	>10

#### Question #4



You are on a recovery team that will be responsible for packaging and transporting the source shown in the photograph above.

Cs-137 
$$A_1 = 2.0 \text{ TBq}$$
  $A_2 = 0.6 \text{ TBq}$ 

#### Question #1

With the original activity of 103.13 Ci (3.816 TBq), what type of package would be required to for transport? (Special Form)

#### **Question #2**

With the decayed activity of 1.76 TBq, what type of package would be required to for transport? (Special Form)

#### Question #3



You are on a recovery team that will be responsible for packaging and transporting the sources shown in the photograph above.

Pu-239  $A_1 = 10 \text{ TBq}$   $A_2 = 0.001 \text{ TBq}$ 

#### Question #1

Each source is 1 Ci (0.037 TBq); total is 0.111 TBq. The sources will be encapsulated to meet special form requirements. What type of package would be required for transport?

#### Question #2

#### **Exercise #1 Answers**

#### Answer #1

The original source activity is above the  $A_1$  and  $A_2$  = 0.4 TBq limit, requiring a Type B

#### Answer #2

The decayed source activity is above the  $A_1$  and  $A_2$  = 0.4 TBq limit, requiring a Type B

#### Answer #3

The source activity is above the Co-60 Transport Security Threshold of 0.3 TBq recommending a minimum – Enhanced Security Level and possibly Additional Security Measures

#### **Exercise #2 Answers**

#### Answer #1

The special form source activity is below the A<sub>1</sub> 10 TBq limit, requiring a Type A

#### Answer #2

- T.I. = Total dose rate at 1 meter in mSv/hr x 100
  - a. <u>1 meter:</u>

#### Answer #3

Yellow - III

#### Answer #4

The source activity is below the Am-241 Transport Security Threshold of 0.6 TBq recommending a minimum – Basic Security Level

#### **Exercise #3 Answers**

#### Answer #1

The original source activity is above the A<sub>1</sub> 2.0 TBq limit, requiring a Type B

#### Answer #2

The decayed source activity is below the A<sub>1</sub> 2.0 TBq limit, requiring a Type A

#### Answer #3

The source activity is above the Cs-137 Transport Security Threshold of 1 TBq recommending a minimum – Enhanced Security Level

#### **Exercise #4 Answers**

#### Answer #1

Pu-239 is a fissile material and the quantity of material does not meet any exception. The total activity is below the  $A_1$  = 10 TBq, therefore a Type A Fissile (AF) container is required

#### Answer #2

The source activity is below the Pu-239 Transport Security Threshold of 0.6 TBq recommending a minimum – Basic Security Level